


TG

ステージ *STAGE* 010



En Technical Guide

De Technischer Leitfaden

Fr Guide technique

Es Guía Técnica

Fi Tekninen Opas

No Teknisk Veiledning

Da Teknisk Vejledning

Sv Teknisk Guide

Pt Guia Técnico

It Guida Tecnica

Tr Teknik Kılavuz

Ro Ghid Tehnic

Pl Przewodnik Techniczny

Cs Technický Průvodce

Zh 技术指南

Ja 技術ガイド



hpi-racing

161002-006-TG

En: Further Information
De: Weitere Informationen
Fr: Informations Complémentaires
Es: Más Información
Fi: Lisätietoja
No: Mer Informasjon
Da: Yderligere Information
Sv: Mer Information

Pt: Mais Informações
It: Ulteriori Informazioni
Tr: Daha Fazla Bilgi
Ro: Informații Suplimentare
Pl: Dalsze Informacje
Cs: Další Informace
Zh: 更多信息
Ja: さらに詳しい情報

QS

En: Quick Start
De: Schnellstart
Fr: Démarrage rapide
Es: Inicio rápido
Fi: Pikakäynnistys
No: Rask oppstart

Da: Hurtig start
Sv: Snabbstart
Pt: Inicio rápido
It: Avvio rapido
Tr: Hızlı başlangıç
Ro: Pornire rapidă

Pl: Szybki start
Cs: Rychlý start
Zh: 快速入门
Ja: クイックスタート

**TG**

En: Technical Guide
De: Technischer Leitfaden
Fr: Guide technique
Es: Guía Técnica
Fi: Tekninen Opas
No: Teknisk Veiledning

Da: Teknisk Vejledning
Sv: Teknisk Guide
Pt: Guia Técnico
It: Guida Tecnica
Tr: Teknik Kılavuz
Ro: Ghid Tehnic

Pl: Przewodnik Techniczny
Cs: Technický Průvodce
Zh: 技术指南
Ja: 技術ガイド

**SG**

En: Startup Guide
De: Startanleitung
Fr: Guide de démarrage
Es: Guía de inicio
Fi: Käynnistysopas
No: Oppstartguide

Da: Opstartsvejledning
Sv: Startguide
Pt: Guia de inicialização
It: Guida all'avvio
Tr: Başlangıç kılavuzu
Ro: Ghid de pornire

Pl: Przewodnik startowy
Cs: Průvodce spuštěním
Zh: 入门指南
Ja: スタートアップガイド

**RMI**

En: Radio Manual
De: Radiohandbuch
Fr: Manuel de la radio
Es: Manual de radio
Fi: Radiokäyttöopas
No: Radiobruksanvisning

Da: Radiobrugervejledning
Sv: Radiomannual
Pt: Manual do rádio
It: Manuale della radio
Tr: Radyo kılavuzu
Ro: Manual de utilizare radio

Pl: Instrukcja obsługi radia
Cs: Návod k použití rádia
Zh: 接收器说明书
Ja: 送信機取扱説明書

**EMI**

En: ESC Manual
De: ESC-Handbuch
Fr: Manuel ESC
Es: Manual ESC
Fi: ESC-käsikirja
No: ESC-manual

Da: ESC-manual
Sv: ESC-manual
Pt: Manual ESC
It: Manuale ESC
Tr: ESC Kılavuzu
Ro: Manual ESC

Pl: Instrukcja ESC
Cs: Manuál ESC
Zh: 电调手册
Ja: ESC取扱説明書

**UG**

En: User Guide
De: Benutzerhandbuch
Fr: Guide de l'utilisateur
Es: Guía del usuario
Fi: Käyttöopas
No: Brukerhåndbok

Da: Brugervejledning
Sv: Användarhandbok
Pt: Guia do utilizador
It: Guida utente
Tr: Kullanıcı Kılavuzu
Ro: Ghid de utilizare

Pl: Instrukcja użytkownika
Cs: Uživatelská příručka
Zh: 用户指南
Ja: ユーザーガイド



En: Scan Me
De: Scanne mich
Fr: Scanne-moi
Es: Escanéame
Fi: Skannaa minut
No: Skann meg

Da: Scan mig
Sv: Skanna mig
Pt: Escaneie-me
It: Scansionami
Tr: Beni Tara
Ro: Scanează-mă

Pl: Przeskanuj mnie
Cs: Naskenuj mě
Zh: 扫描二维码
Ja: スキャンして



En: Parts List
De: Stückliste
Fr: Nomenclature
Es: Liste Des Pièces
Fi: Osaluettelo
No: Reservedelsliste
Da: Deleliste
Sv: Reservdelslista

Pt: Lista De Peças
It: Elenco Dei Componenti
Tr: Parça Listesi
Ro: Listă De Piese
Pl: Lista Części
Cs: Seznam Dílů
Zh: 零件清单
Ja: 部品表

Parts # Description


6163	Servo Tape 20x100mm (10pcs)
6819	Silicon O-Ring P-3 (Red) (5pcs)
6927	Pinion Gear 27 Tooth (48dp)
75106	Body Pin (6mm/Black/Medium/20pcs)
75122	Steering Block Bushing (4pcs)
87540	Washer 5x10x0.2mm (10pcs)
101221	Diff Case Gasket (3pcs)
101230	Diff Shaft 5x23.5mm (2pcs)
107895	Button Head Screw M3x25mm (10pcs)
113713	Drive Shaft (45mm)
160380	Flat Head Screw M3x25mm (Hex Socket/10pcs)
160544	HPI SD-07WR Servo (Water-Resistant/6.0V/7Kg/Plastic Geared)
160549	HPI TF-51/RF-51 2.4Ghz Radio Set
160554	HPI TF-51 4-Ch Transmitter
160555	HPI RF-51 4Ch Receiver
161010	Main Chassis
161011	Top Deck Set
161012	Chassis Support Set
161013	Front Bulkhead Set
161014	Rear Bulkhead Set
161015	Rear Gearbox Set
161016	Transmission Gear Set
161017	Suspension Arm Set
161018	Upright Set
161019	Steering & Hinge Pin Holder Set
161020	Linkage Set
161021	Chassis Part Set
161022	Body Mount & Spacer Set
161023	Front Bumper & Diffuser Set
161024	Body Post Set
161025	Hex Hub Set
161026	Ball Stud 4.8x14mm (10pcs)
161027	Front Axle (2pcs)
161028	Top Hat Bushing (2pcs)
161029	Top Shaft
161030	Idler Shaft
161031	Shaft 5x30mm (4pcs)
161034	Steering Post (2pcs)
161035	Hinge Pin Set
161036	Body Post Ball End (Steel/4pcs)
161037	Cone Magnet Nut (4pcs)
161038	Drive Gear 20T (48DP)
161039	Motor Plate Set (2pcs)
161043	Foam Bumper
161044	Pin 2x7.7mm (10pcs)
161045	Servo Saver Set
161046	Shock Cap Set
161047	Diff Gear Set
161048	Spur Gear 80T 48DP
161049	Shock Shaft 3x30mm (2pcs)
161050	Axle Shaft (5x26mm/2pcs)
161051	Shock Bladder (4pcs)
161052	Turnbuckle M3x30mm (2pcs)

Parts # Description

161053	Step Screw M3x55mm (Hex Socket/4pcs)
161054	Ball Stud 4.8x14mm (10pcs)
161055	Universal Magnetic Body Mount Set (4pcs)
161056	Solid Servo Horn Set
161057	Shock Spring 14x30x1.0mm/4.25 Coils (Black/2pcs)
161058	Shock Spring 14x31.5x1.0mm/4.5 Coils (Black/2pcs)
161060	Magnet Mount Double Sided Tape (8pcs)
161061	Screw Shaft M3x2.5x10mm (10pcs)
161062	Assembled Shock Set (4pcs)
161063	SC-3SWP2 Waterproof ESC with XT-60
161064	Firebolt 20T 540 Motor
161065	FLX-D10 80A Sensored Flux ESC
161066	FLX-D10-3650 10.5T Sensored Flux Motor
161067	HPI SX-12MGLP Servo (7.4V/12kg/Metal Geared)
161068	D-Box3 Lite Drift Gyro
161069	D-Box3 Pro Drift Gyro
161199	M3x3mm Set Screw (10pcs)
161299	Flat Head Screw M2x4mm (Hex Socket/10pcs)
161584	Washer 3x7x0.2mm (10pcs)
120298	Button Head Screw M2x6mm (10pcs)
A020	O-Ring P-5 (4pcs)
B020	Ball Bearing 5x8x2.5mm (2pcs)
B021	Ball Bearing 5x10x4mm (2pcs)
B030	Ball Bearing 10x15x4mm (2pcs)
Z082	Flat Head Screw M3x8mm (Hex Socket/10pcs)
Z083	Flat Head Screw M3x10mm (Hex Socket/10pcs)
Z084	Flat Head Screw M3x12mm (Hex Socket/10pcs)
Z150	Antenna Pipe Set
Z216	Button Head Screw M3x15mm (Hex Socket/4pcs)
Z242	E-Clip E2mm (20pcs)
Z264	Pin 2x10mm Silver (10pcs)
Z351	Button Head Screw M3x6mm (Hex Socket/10pcs)
Z352	Button Head Screw M3x8mm (Hex Socket/10pcs)
Z353	Button Head Screw M3x10mm (Hex Socket/10pcs)
Z354	Button Head Screw M3x12mm (Hex Socket/10pcs)
Z356	Button Head Screw M3x18mm (Hex Socket/10pcs)
Z449	Flat Head Screw M2.5x12mm (Hex Socket/10pcs)
Z663	Lock Nut M3 (6pcs)
Z664	Lock Nut M4 (4pcs)
Z684	Flange Lock Nut M4 (4pcs)
Z702	Set Screw M3x5mm (10pcs)
Z706	Set Screw M3x12mm (6pcs)
Z707	Set Screw M3x15mm (6pcs)
Z708	Set Screw M3x18mm (6pcs)


En: Exploded Views
 De: Explosionszeichnung
 Fr: Vue Éclatée
 Es: Vista Explosiónada

Fi: Räjätyskuva
 No: Sprengskisse
 Da: Eksploderet Visning
 Sv: Exploderad Vy




Pt: Vista Explodida
It: Vista Esplosa
Tr: Patlatılmış Görünüm
Ro: Vedere Explodată

Pl: Widok Rozłożony
Cs: Rozložený Pohled
Zh: 爆炸图
Ja: 分解図




ステージ
STAGE 010
FLUX




3-2

En: Rear Assembly
De: Heckbaugruppe
Fr: Assemblage Arrière
Es: Ensamblaje Trasero
Fi: Takakokoonpano
No: Bakmontering
Da: Baksamling
Sv: Bakre Montering


Pt: Montagem Traseira
It: Assemblaggio Posteriore
Tr: Arka Montaj
Ro: Ansamblu Posterior
Pl: Zespół Tylny
Cs: Zadní Sestava
Zh: 后部组件
Ja: リアアセンブリ







Pt: Montagem Traseira
It: Assemblaggio Posteriore
Tr: Arka Montaj
Ro: Ansamblu Posterior


Pl: Zespół Tylny
Cs: Zadní Sestava
Zh: 后部组件
Ja: リアアセンブリ






Pt: Montagem Frontal
It: Assemblaggio Anteriore
Tr: Ön Montaj
Ro: Ansamblu Frontal

Pl: Zespół Przedni
Cs: Přední Sestava
Zh: 前部组件
Ja: フロントアセンブリ







3-6

En: Gearbox Assembly
De: Getriebeeinbau
Fr: Assemblage De La Boîte De Vitesses
Es: Ensamblaje De La Caja De Cambios
Fi: Vaihteiston Kokoonpano
No: Montering Av Girkasse
Da: Montering Af Gearkasse
Sv: Montering Av Väckellåda

Pt: Montagem Da Caixa De Câmbio
It: Assemblaggio Del Cambio
Tr: Şanzıman Montajı
Ro: Asamblare Cutie De Viteze
Pl: Montaż Skrzyni Biegów
Cs: Montáž Převodovky
Zh: 变速箱装配
Ja: ギアボックスの組立






3-8

En: Shock Assembly
De: Stoßdämpfer-Montage
Fr: Assemblage De L'amortisseur
Es: Montaje Del Amortiguador
Fi: Iskunjaimennin Kokoonpano
No: Støtdempermontering
Da: Støddæmper Samling
Sv: Stötdämparmontering

Pt: Montagem Do Amortecedor
It: Assemblaggio Dell'ammortizzatore
Tr: Amortisör Montajı
Ro: Asamblare Amortizor
Pl: Montaż Amortyzatora
Cs: Montáž Tlumiče
Zh: 缓冲器组装
Ja: ショックアセンブリ

Front

Rear





HPI RACING A/S
www.hpiracing.com
HPI Racing A/S
Jegindavej 21
DK - 8800 Viborg
Denmark
Email: info@hpiracing.com

Serial Number
Seriennummer
Numéro de série
シリアルナンバー

